












Find the Right Filter for Your Under the Sink Water Filtration

Which 3M™ Aqua-Pure™ filter best suits your needs?

									
	AP717	AP Easy Complete	3MDW301	AP Easy Cyst-FF	3MFF100	3MRO301	3MRO401	3MRO501 <i>requires 120 Volts</i>	AP Easy Complete Cooler
Where located	Refrigerator	Under Sink, Dedicated Faucet		Under Sink, Full Flow		Under Sink, Reverse Osmosis			Water Coolers
Replacement Cartridge	AP717	AP Easy C-Complete	3MDW311	AP Easy C-Cyst-FF	3MFF101	3MROP310/ 3MROP416/ 3MROM413	3MROP411/ 3MROP416/ 3MROP412/ 3MROM413	3MROP411/ 3MROP416/ 3MROP412/ 3MROM413	AP Easy C-Complete
Life ¹	6 months	6 months	12 months	6 months	12 months	Cartridges 12 months, Membrane 36 months	Cartridges 12 months, Membrane 36 months	Cartridges 12 months, Membrane 36 months	6 months
Micron Rating	5	0.5	0.2	0.5	0.2	5	5	5	0.5
Reduction Claims									
Sediment/Particulate	✓	✓	✓	✓	✓	✓	✓	✓	✓
Chlorine Taste/Odor	✓	✓	✓	✓	✓	✓	✓	✓	✓
Chloramines			✓						
Cyst		✓	✓	✓	✓	✓	✓	✓	✓
Scale	✓								
Lead		✓	✓		✓	✓	✓	✓	✓
Mercury		✓							✓
Select VOCs		✓			✓				✓
VOCs			✓						
Arsenic, Barium, Cadmium, Chromium, Copper, Fluoride, Radium, Selenium and TDS						✓	✓	✓	
Nitrate/Nitrite								✓	
Asbestos			✓						

Under sink water filtration systems are great solutions to provide cleaner, clearer and great tasting drinking and cooking water by reducing a wide range of contaminants that may be present in the local water.

3M Water Filters can reduce the following from your water supply²:

Sediment: Can damage plumbing and appliances over time. It includes rust particles that can cause brown, yellow or orange spots on clothing, fixtures and toilets.

Taste/Odor: Chlorine is used by water treatment plants to kill harmful bacteria and organisms. Chlorine has a recognizable taste and odor that can be unpleasant.

Cysts: Encapsulated forms of certain single cell parasites like oocysts of Cryptosporidium that may be present in drinking water and resistant to normal chlorination.

Hardness/Scale: Scale can cause water to fail to generate a lather with soap, and can build-up on and create the failure of heating elements, piping, valves, solenoids and more. This is caused by the presence of calcium and magnesium ions.

Lead: Water is naturally a solvent and can leach lead and other heavy metals from brass taps and plumbing fittings. Lead may be present in pipes and the solder used to connect pipes.

Chemicals/VOCs: Contaminants resulting from pesticide runoff and gasoline leakage into ground water (VOCs — Volatile Organic Chemicals).

¹Filter life depends on local water quality. Replace filter cartridge no later than at the indicated intervals, or earlier if there is a drop in flow rate or change in odor or taste.

²Depending on the filter media selected.



Find the Right Filter for Your Scale Inhibition System and Whole House Water Filtration

Which 3M™ Aqua-Pure™ filter best suits your needs?



AP430SS AP801B / AP801T AP802B / AP802T AP902 AP903 AP904

Where Located	Water Heater	Whole House / Point of Entry								
Replacement Cartridge	AP431	AP810	AP811	AP817	AP810-2	AP811-2	AP817-2	AP910R	AP917HD	AP917HD-S
Filter Life ¹	6 months	6 months	6 months	6 months	6 months	6 months	6 months	Up to 12 months	Up to 12 months	Up to 12 months
Micron Rating	N/A	5	25	25	5	25	25	5	5	5
Reduction Claims										
Sediment/Particulate		✓	✓	✓	✓	✓	✓	✓	✓	✓
Chlorine Taste/Odor				✓			✓		✓	✓
Chloramines										
Cyst										
Scale	✓									✓
Lead										
Mercury										
Select VOCs										
VOCs										
Asbestos										

Scale Inhibition System

The 3M™ Aqua-Pure™ Whole House Scale Inhibition Water Treatment System AP430SS is a great add on to your tank and tankless water heater sale.

This water treatment system helps protect tank and tankless water heaters by providing a consistent, controlled dose of polyphosphate scale inhibitor, plus it helps protect the piping system from corrosion.

Scale Inhibition System

- Helps maintain efficiency and extend the life of tank and tankless water heater system
- Stainless steel head
- ¾" inlet/outlet connection

Whole House Water Filtration

Whole house water filter systems are great solutions to help protect your pipes and appliances as well as offer you great tasting drinking water from anywhere in the home.

3M™ Aqua-Pure™ AP800 Series Whole House Water Filtration System

- High flow designed with 1" NPT connections
- Two year limited warranty to help provide long-term operation, superior factory support and service
- Designed with built-in pressure relief for convenient cartridge change out



3M™ Aqua-Pure™ AP900 Series Whole House Water Filtration System

- Three levels of filtration available for different water quality issues
- Stainless steel head with limited 25 year warranty
- Easy SQC replacement change-out style



Enjoy healthy, great tasting water straight from the tap. Our products are designed for a variety of homes and requirements.

3M Water Filters can reduce the following from your water supply²:

- Sediment:** Can damage plumbing and appliances over time. It includes rust particles that can cause brown, yellow or orange spots on clothing, fixtures and toilets.
- Taste/Odor:** Chlorine is used by water treatment plants to kill harmful bacteria and organisms. Chlorine has a recognizable taste and odor that can be unpleasant.
- Cysts:** Encapsulated forms of certain single cell parasites like oocysts of Cryptosporidium that may be present in drinking water and resistant to normal chlorination.

- Hardness/Scale:** Scale can cause water to fail to generate a lather with soap, and can build-up on and create the failure of heating elements, piping, valves, solenoids and more. This is caused by the presence of calcium and magnesium ions.
- Lead:** Water is naturally a solvent and can leach lead and other heavy metals from brass taps and plumbing fittings. Lead may be present in pipes and the solder used to connect pipes.
- Chemicals/VOCs:** Contaminants resulting from pesticide runoff and gasoline leakage into ground water (VOCs — Volatile Organic Chemicals).

¹Filter life depends on local water quality. Replace filter cartridge no later than at the indicated intervals, or earlier if there is a drop in flow rate or change in odor or taste.

²Depending on the filter media selected.