



# 3M<sup>™</sup> Attest<sup>™</sup> Steam Chemical Integrator Guide

### **Recommended Placement**

#### Wrapped Towel Pack or Gown, **Towel and Drape Pack**

Place CI in geometric center,



#### **Manufacturer Supplied Container** (multi-level, perforated tray, needs to be wrapped)\* Place CIs in center on each level.



#### Wrapped Instrument Tray

Place CI in geometric center, not on top.



#### Rigid Containers\*

Place two CIs in opposite corners of each level.




#### **Peel Pouches**

When an internal CI is visible, an external Type 1 CI is not required.





#### **IUSS Sterilization** of Rigid Containers\*


Place two CIs in opposite corners.



# Interpretation







## Contact your 3M Representative or visit 3M.co.uk/sterilisation

Loughborough LE11 5RB 01509 611611

The Iveagh Building Carrickmines Park Carrickmines Dublin 18 00 353 (01) 280 3555

> \*The manufacturers of the device and container system should also be consulted for recommendation on number and placement of internal chemical indicators.

@ 2020 3M. All rights reserved. 3M and Attest are marks and/or registered marks of 3M.

ANSI/AAMI ST79:2017 Internal CIs should be placed a) so that one CI is visible to the person opening the package; b) in the area or areas considered least accessible to steam penetration; and c) in accordance with all applicable written IFUs

3M™ Attest™ Steam Chemical Integrators, Type 5 conform with ISO 11140-1:2014.